

Таблица применения вариаторных ремней для снегоходов Arctic Cat

Year	Model	CC	Part Number Belt
2010			
2010	BEARCAT 570	565	0627-067
2010	BEARCAT 570 XT	565	0627-046
2010	BEARCAT Z1 XT	1056	0627-047
2010	CFR8	794	0627-060
2010	CFR1000	1000	0627-060
2010	CROSSFIRE 6	599	0627-046
2010	CROSSFIRE 8	794	0627-060
2010	CROSSFIRE 8 SNO PRO	794	0627-060
2010	F5 LXR	499	0627-067
2010	F570	565	0627-067
2010	F6 SNO PRO	599	0627-046
2010	F8	794	0627-046
2010	F8 LXR	794	0627-046
2010	F8 SNO PRO	794	0627-046
2010	M6	599	0627-046
2010	M8	794	0627-046
2010	M8 HCR	794	0627-046
2010	M8 SNO PRO	794	0627-046
2010	M1000 SNO PRO	999	0627-060
2010	SNO PRO 500	499	0627-047
2010	T570	565	0627-067
2010	TZ1	1056	0627-069
2010	TZ1 LXR	1056	0627-069
2010	TZ1 TURBO LXR	1056	0627-073
2010	Z1	1056	0627-069
2010	Z1 TURBO	1056	0627-073
2010	Z1 LXR	1056	0627-073
2010	Z1 Turbo EXT	1056	0627-073
2010	Z1 Turbo LXR	1056	0627-073
2010	Z1 TURBO SNO PRO	1056	0627-073
2010	SNOCROSS SNO PRO 600	600	0627-075

2009

2009	BEARCAT 570	565	0627-067
2009	BEARCAT 570 XT	565	0627-046
2009	BEARCAT Z1 XT	1056	0627-047
2009	CROSSFIRE 500	499	0627-046
2009	CROSSFIRE 600	599	0627-046
2009	CROSSFIRE 800	794	0627-046
2009	CROSSFIRE R 800	800	0627-046
2009	CROSSFIRE 800 SNO PRO	794	0627-046
2009	CROSSFIRE 1000	999	0627-060
2009	CROSSFIRE 1000 SNO PRO	999	0627-060
2009	CROSSFIRE R 1000	1000	0627-060
2009	F5	499	0627-067
2009	F5 LXR	499	0627-067
2009	F570	565	0627-067
2009	F6 SNO PRO	599	0627-046
2009	F8	794	0627-046
2009	F8 SNO PRO	794	0627-046
2009	F8 LXR	794	0627-046
2009	F1000	999	0627-060
2009	F1000 LXR	999	0627-060
2009	F1000 SNO PRO	999	0627-060
2009	M6	599	0627-046
2009	M8	794	0627-046
2009	M8 SNO PRO	794	0627-046
2009	M1000	999	0627-060
2009	M1000 SNO PRO	999	0627-060
2009	T500	499	0627-067
2009	T570	565	0627-067
2009	TZ1	1056	0627-047
2009	TZ1 TOURING	1056	0627-047
2009	TZ1 TURBO	1056	0627-073
2009	Z1	1056	0627-047
2009	Z1 BEARCAT	1056	0627-047
2009	Z1 TURBO	1056	0627-073

2008

2008	BEARCAT 570	565	0627-013
2008	BEARCAT WIDE TRACK	660	0627-033
2008	BEARCAT WIDE TRACK TURBO	660	0627-049
2008	BEARCAT WT TURBO ARTICULATING	660	0627-049
2008	CROSSFIRE 5	499	0627-046
2008	CROSSFIRE 6	599	0627-046
2008	CROSSFIRE 8	794	0627-046
2008	CROSSFIRE 8 SNO PRO	794	0627-046
2008	CROSSFIRE 1000	999	0627-060
2008	CROSSFIRE 1000 SNO PRO	999	0627-060
2008	F5	499	0627-046
2008	F5 LXR	499	0627-046
2008	F570	565	0627-046
2008	F6	599	0627-046
2008	F6 LXR	599	0627-046
2008	F6 SNO PRO	599	0627-046
2008	F8	794	0627-046
2008	F8 LXR	794	0627-046
2008	F8 SNO PRO	794	0627-046
2008	F1000	999	0627-060
2008	F1000 LXR	999	0627-060
2008	F1000 SNO PRO	999	0627-060
2008	JAGUAR Z1	1056	0627-047
2008	M6	599	0627-046
2008	M8	794	0627-046
2008	M8 SNO PRO	794	0627-046
2008	M1000	999	0627-060
2008	M1000 SNO PRO	999	0627-060
2008	PANTHER 370	367	0627-021
2008	PANTHER 660	660	0627-013
2008	T500	499	0627-046
2008	T570	565	0627-046
2008	T660 TOURING	660	0627-013
2008	TZ1	1056	0627-047
2008	TZ1 TOURING LXR	1056	0627-047

2007

2007	BEARCAT 570	565	0627-013
2007	BEARCAT WT	660	0627-033
2007	BEARCAT WT TURBO	660	0627-049
2007	CROSSFIRE 5	499	0627-046
2007	CROSSFIRE 6	599	0627-046
2007	CROSSFIRE 8	794	0627-046
2007	CROSSFIRE 8 SNO PRO	794	0627-046
2007	CROSSFIRE 1000	999	0627-060
2007	CROSSFIRE 1000 SNO PRO	999	0627-060
2007	F5	499	0627-046
2007	F5 LXR	499	0627-046
2007	F6	599	0627-046
2007	F6 SNO PRO	599	0627-046
2007	F8	794	0627-046
2007	F8 LXR	794	0627-046
2007	F8 SNO PRO	794	0627-046
2007	F1000	999	0627-060
2007	F1000 LXR	999	0627-060
2007	F1000 SNO PRO	999	0627-060
2007	JAGUAR Z1	1056	0627-047
2007	M6	599	0627-046
2007	M8	794	0627-046
2007	M8 SNO PRO	794	0627-046
2007	M1000	999	0627-060
2007	M1000 SNO PRO	999	0627-060
2007	PANTHER 370	367	0627-021
2007	PANTHER 570	565	0627-021
2007	PANTHER 660 TRAIL	660	0627-013
2007	PANTHER 660 TOURING	660	0627-013
2007	T660 TURBO TRAIL	660	0627-048
2007	T660 TURBO TOURING	660	0627-048
2007	Z 370	367	0627-021
2007	Z 370 LX	367	0627-021
2007	Z 570	565	0627-021
2007	Z 570 LX	565	0627-021

2006

2006	BEARCAT 570	565	0627-013
2006	BEARCAT WIDE TRACK	660	0627-033
2006	BEARCAT WT TURBO	660	0627-049
2006	CROSSFIRE 500	599	0627-036
2006	CROSSFIRE 600 EFI	599	0627-036
2006	CROSSFIRE 600 EFI SNO PRO	599	0627-036
2006	CROSSFIRE 700 EFI	698	0627-036
2006	CROSSFIRE 700 EFI EB	698	0627-036
2006	CROSSFIRE 700 EFI SNO PRO	698	0627-036
2006	FIRECAT 500	499	0627-044
2006	FIRECAT 500 SNO PRO	499	0627-044
2006	FIRECAT 600 EFI	599	0627-044
2006	FIRECAT 600 EFI r	599	0627-020
2006	FIRECAT 600 EFI SNO PRO	599	0627-044
2006	FIRECAT 700	698	0627-044
2006	FIRECAT 700 EFI	698	0627-044
2006	FIRECAT 700 EFI r	698	0627-035
2006	FIRECAT 700 EFI SNO PRO	698	0627-044
2006	FIRECAT 700 SNO PRO	698	0627-044
2006	KING CAT 900 EFI	862	0627-020
2006	M5 EFI	499	0627-036
2006	M6 EFI	599	0627-036
2006	M7	698	0627-036
2006	M7 EFI	698	0627-036
2006	M7 EFI LIMITED	698	0627-036
2006	PANTHER 370	367	0627-021
2006	PANTHER 570	565	0627-021
2006	PANTHER 660	660	0627-013
2006	SABERCAT 500 EFI	499	0627-020
2006	SABERCAT 600 EFI LX	599	0627-020
2006	SABERCAT 700 EFI	698	0627-035
2006	T660	660	0627-013
2006	T660 TURBO TRAIL	660	0627-048
2006	T660 TURBO TOURING	660	0627-048
2006	Z 370	367	0627-021
2006	Z 440 LX	431	0627-021
2006	Z 570	565	0627-021
2006	ZR 900 EFI	862	0627-045
2006	ZR 900 EFI SNO PRO	862	0627-045
2006	440 SNO PRO		0627-010
2006	440 SNO PRO MOD		0627-049

2005

2005	BEARCAT 570	565	0627-013
2005	BEARCAT WIDE TRACK	660	0627-033
2005	FIRECAT 500	499	0627-034
2005	FIRECAT 500 SNO PRO	499	0627-034
2005	FIRECAT 600 EFI	599	0627-034
2005	FIRECAT 600 EFI EXT	599	0627-034
2005	FIRECAT 600 EFI r	599	0627-020
2005	FIRECAT 600 EFI SNO PRO	599	0627-034
2005	FIRECAT 700	699	0627-034
2005	FIRECAT 700 EFI	699	0627-034
2005	FIRECAT 700 EFI EXT	699	0627-034
2005	FIRECAT 700 EFI r	699	0627-035
2005	FIRECAT 700 EFI SNO PRO	699	0627-034
2005	FIRECAT 700 SNO PRO	699	0627-034
2005	KING CAT 900	862	0627-020
2005	KING CAT 900 EFI	862	0627-020
2005	M5	499	0627-036
2005	M6 EFI	599	0627-036
2005	M7 EFI	698	0627-036
2005	M7 EFI LE	698	0627-036
2005	PANTERA 550	550	0627-021
2005	PANTERA 600 EFI	599	0627-020
2005	PANTHER 370 r		0627-021
2005	PANTHER 570	565	0627-021
2005	SABERCAT 500	500	0627-020
2005	SABERCAT 600 EFI	599	0627-020
2005	SABERCAT 600 EFI EXT	599	0627-020
2005	SABERCAT 600 EFI LX	599	0627-020
2005	SABERCAT 700 EFI	699	0627-035
2005	SABERCAT 700 EFI EXT	699	0627-035
2005	SABERCAT 700 EFI LX	699	0627-035
2005	T660	660	0627-013
2005	T660 TURBO	660	0627-028
2005	T660 TURBO ST	660	0627-028
2005	T660 TURBO ST EB	660	0627-028
2005	T660 TURBO TOURING	660	0627-028
2005	Z 370		0627-021
2005	Z 370 LX		0627-021
2005	Z 440 LX		0627-021
2005	Z 570	565	0627-021

2005	Z 570 LX	565	0627-021
2005	ZR 900	862	0627-032
2005	ZR 900 EFI	862	0627-032
2005	ZR 900 EFI SNO PRO	862	0627-032
2005	ZR 900 SNO PRO	862	0627-032
2005	440 SNO PRO		0627-010
2005	440 SNO PRO MOD		0627-020

2004

2004	BEARCAT 570 LT	565	0627-013
2004	BEARCAT WIDETRACK	660	0627-033
2004	F5 FIRECAT	499	0627-020
2004	F5 FIRECAT SNO PRO	499	0627-020
2004	F6 FIRECAT	599	0627-031
2004	F6 FIRECAT EFI	599	0627-031
2004	F6 FIRECAT EFI SNO PRO	599	0627-031
2004	F6 FIRECAT SNO PRO	599	0627-031
2004	FIRECAT 600 EB		0627-035
2004	F7 FIRECAT	698	0627-031
2004	F7 FIRECAT EFI	698	0627-031
2004	F7 FIRECAT EFI EXT	698	0627-031
2004	F7 FIRECAT EFI SNO PRO	698	0627-031
2004	F7 FIRECAT SNO PRO	698	0627-031
2004	KING CAT 900	862	0627-020
2004	MOUNTAIN CAT 570 IM	565	0627-020
2004	MOUNTAIN CAT 600 IM EFI	599	0627-020
2004	MOUNTAIN CAT 800 IM EFI 151	785	0627-020
2004	MOUNTAIN CAT 800 IM EFI 159	785	0627-020
2004	MOUNTAIN CAT 900 IM 151	862	0627-020
2004	MOUNTAIN CAT 900 IM 159	862	0627-020
2004	MOUNTAIN CAT 900 IM EFI 151	862	0627-020
2004	MOUNTAIN CAT 900 IM EFI 159	862	0627-020
2004	PANTERA 550	550	0627-021
2004	PANTERA 600 EFI	599	0627-020
2004	PANTERA 800 EFI	785	0627-020
2004	PANTHER 370	367	0627-021
2004	PANTHER 570	565	0627-021
2004	SABERCAT 500	499	0627-020
2004	SABERCAT 500 LX	499	0627-020
2004	SABERCAT 600	599	0627-031
2004	SABERCAT 600 EFI	599	0627-031
2004	SABERCAT 600 EFI EXT	599	0627-031
2004	SABERCAT 600 EFI LX	599	0627-031
2004	SABERCAT 600 LX	599	0627-031
2004	SABERCAT 700 EFI	698	0627-031
2004	SABERCAT 700 EFI EXT	698	0627-031
2004	SABERCAT 700 EFI LX	698	0627-031
2004	T660 SPORT	660	0627-028
2004	T660 TURBO	660	0627-028

2004	T660 TOURING	660	0627-013
2004	Z 370	367	0627-021
2004	Z 370 LX	367	0627-021
2004	Z 440 LX	431	0627-021
2004	Z 570	565	0627-021
2004	Z 570 LX	565	0627-021
2004	ZR 900	862	0627-032
2004	ZR 900 EFI	862	0627-032
2004	ZR 900 EFI SNO PRO	862	0627-032
2004	ZR 900 SNO PRO	862	0627-032
2004	440 SNO PRO	431	0627-010

2003

2003	4-STROKE TOURING	658	0627-013
2003	4-STROKE TRAIL	658	0627-013
2003	BEARCAT WIDETRACK	658	0627-026
2003	FIRECAT 440 PRO	499	0627-010
2003	FIRECAT F5	499	0627-020
2003	FIRECAT F5 SNO PRO	499	0627-020
2003	FIRECAT F7 EFI	698	0627-035
2003	FIRECAT F7 EFI SNO PRO	698	0627-035
2003	MOUNTAIN CAT 570	565	0627-020
2003	MOUNTAIN CAT 600 EFI	599	0627-020
2003	MOUNTAIN CAT 800 EFI	785	0627-020
2003	MOUNTAIN CAT 900	862	0627-020
2003	PANTERA 550	550	0627-021
2003	PANTERA 600 EFI	599	0627-020
2003	PANTERA 800 EFI	785	0627-020
2003	PANTHER 370 R	367	0627-021
2003	PANTHER 570 ESR	565	0627-021
2003	Z 370	367	0627-021
2003	Z 440 ESR	431	0627-021
2003	Z 570	565	0627-021
2003	Z 440 SNO PRO L/C	431	0627-010
2003	ZL 550	550	0627-020
2003	ZL 600 EFI	599	0627-020
2003	ZL 600 EFI SS	599	0627-020
2003	ZL 800 EFI ESR	758	0627-020
2003	ZL 800 EFI SS	785	0627-020
2003	ZR 800 EFI	785	0627-020
2003	ZR 800 EFI SNO PRO	785	0627-020
2003	ZR 900	862	0627-020
2003	ZR 900 SNO PRO	862	0627-035

2002

2002	4-STROKE TOURING	660	0627-021
2002	4-STROKE TRAIL	660	0627-021
2002	BEARCAT WIDETRACK	550	0627-014
2002	FIRECAT F2		0627-010
2002	MOUNTAIN CAT 500	497	0627-020
2002	MOUNTAIN CAT 570	565	0627-020
2002	MOUNTAIN CAT 600 EFI	599	0627-020
2002	MOUNTAIN CAT 800	785	0627-020
2002	MOUNTAIN CAT 800 EFI	785	0627-020
2002	MOUNTAIN CAT 1000	999	0627-020
2002	PANTERA 550	550	0627-021
2002	PANTERA 600 EFI	599	0627-020
2002	PANTERA 800 EFI	785	0627-020
2002	PANTHER 440	431	0627-021
2002	PANTHER 570	565	0627-021
2002	THUNDERCAT	999	0627-020
2002	Z 370	367	0627-021
2002	Z 440	431	0627-021
2002	Z 570	565	0627-021
2002	Z 570 SS	565	0627-021
2002	ZL 500	497	0627-020
2002	ZL 550	550	0627-020
2002	ZL 600 EFI	599	0627-020
2002	ZL 600 EFI SS	599	0627-020
2002	ZL 800 EFI ESR	785	0627-020
2002	ZL 800 EFI SS	785	0627-020
2002	ZR 440 SNO PRO	431	0627-010
2002	ZR 500	497	0627-020
2002	ZR 500 CC	497	0627-020
2002	ZR 500 LE	497	0627-020
2002	ZR 600	599	0627-020
2002	ZR 600 EFI	599	0627-020
2002	ZR 800	785	0627-020
2002	ZR 800 CC	785	0627-020
2002	ZR 800 EFI	785	0627-020
2002	ZRT 600	594	0627-020

2001

2001	BEARCAT WIDETRACK	550	0627-014
2001	MOUNTAIN CAT 500 EFI	497	0627-020
2001	MOUNTAIN CAT 600 EFI	599	0627-020
2001	MOUNTAIN CAT 600 VEV	599	0627-020
2001	MOUNTAIN CAT 800	785	0627-020
2001	MOUNTAIN CAT 1000	999	0627-020
2001	PANTERA 580 EFI	580	0627-020
2001	PANTERA 1000	999	0627-020
2001	PANTHER 370	370	0627-013
2001	PANTHER 440	431	0627-012
2001	PANTHER 550	550	0627-021
2001	THUNDERCAT	1000	0627-020
2001	TRIPLE TOURING 600	594	0627-020
2001	Z 370	370	0627-021
2001	Z 440	431	0627-021
2001	ZL 500 EFI ESR	497	0627-020
2001	ZL 550	550	0627-020
2001	ZL 600 EFI	599	0627-020
2001	ZL 600 EFI ESR	599	0627-020
2001	ZL 800 ESR	785	0627-020
2001	ZR 440 SNO PRO	431	0627-010
2001	ZR 500	497	0267-020
2001	ZR 500 EFI	497	0627-020
2001	ZR 600	599	0627-020
2001	ZR 600 EFI	599	0627-020
2001	ZR 600 VEV	599	0627-020
2001	ZR 800	785	0627-020
2001	ZRT 600	594	0627-020
2001	ZRT 800	794	0627-020

2000

2000	BEARCAT 340	339	0627-013
2000	BEARCAT 440	431	0627-014
2000	BEARCAT WIDETRACK	550	0627-014
2000	PANTERA 580 EFI	580	0627-020
2000	PANTERA 1000	999	0627-020
2000	PANTHER 340	339	0627-012
2000	PANTHER 440	431	0627-012
2000	PANTHER 550	550	0627-021
2000	POWDER SPECIAL 500 EFI	497	0627-020
2000	POWDER SPECIAL 600	599	0627-020
2000	POWDER SPECIAL 600 EFI	599	0627-020
2000	POWDER SPECIAL 700	700	0627-020
2000	THUNDERCAT	999	0627-020
2000	THUNDERCAT MOUNTAIN CAT	999	0627-020
2000	TRIPLE TOURING	594	0627-020
2000	Z 370	367	0627-021
2000	Z 370 ES	367	0627-021
2000	Z 440	431	0627-021
2000	Z 440 ES	431	0627-021
2000	ZL 440	436	0627-021
2000	ZL 500	497	0627-020
2000	ZL 500 EFI	497	0627-020
2000	ZL 550 ESR	550	0627-021
2000	ZL 580 EFI ESR	580	0627-020
2000	ZL 600	599	0627-020
2000	ZL 600 EFI	599	0627-020
2000	ZL 700	700	0627-020
2000	ZR 440 SNO PRO	436	0627-010
2000	ZR 500	497	0627-020
2000	ZR 500 EFI	497	0627-020
2000	ZR 600	599	0627-020
2000	ZR 600 EFI	599	0627-020
2000	ZR 700	700	0627-020
2000	ZRT 600	594	0627-020
2000	ZRT 800	794	0627-020

1999

1999	BEARCAT 340	339	0627-013
1999	BEARCAT 440	431	0627-014
1999	BEARCAT 550 WIDETRACK	550	0627-014
1999	JAG 340	339	0627-012
1999	JAG 440	431	0627-012
1999	PANTHER 340	339	0627-012
1999	PANTHER 440	431	0627-012
1999	PANTHER 550	550	0627-021
1999	PANTERA 580 EFI	580	0627-021
1999	PANTERA 800	794	0627-020
1999	POWDER SPECIAL 500 EFI	497	0627-020
1999	POWDER SPECIAL 600	599	0627-020
1999	POWDER SPECIAL 600 EFI	599	0627-020
1999	POWDER SPECIAL 700	700	0627-020
1999	THUNDERCAT	1000	0627-020
1999	THUNDERCAT MOUNTAIN CAT	1000	0627-020
1999	TRIPLE TOURING 600	594	0627-020
1999	Z 370	367	0627-021
1999	Z 440	431	0627-020
1999	ZL 440	436	0627-021
1999	ZL 500	497	0627-020
1999	ZL 500 EFI	497	0627-020
1999	ZL 600	599	0627-020
1999	ZL 600 EFI	599	0627-020
1999	ZR 440	440	0627-020
1999	ZR 500	497	0627-020
1999	ZR 500 EFI	497	0627-020
1999	ZR 600	599	0627-020
1999	ZR 600 EFI	599	0627-020
1999	ZR 700	700	0627-020
1999	ZRT 600	594	0627-020
1999	ZRT 800	794	0627-020

1998

1998	BEARCAT 340	340	0627-013
1998	BEARCAT 440	431	0627-014
1998	BEARCAT WIDETRACK	550	0627-014
1998	COUGAR	550	0627-021
1998	COUGAR DELUXE	550	0627-021
1998	COUGAR MOUNTAIN CAT	550	0627-021
1998	EXT 580 EFI	580	0627-021
1998	EXT DELUXE	580	0627-021
1998	EXT 600	594	0627-020
1998	EXT 600 TOURING	594	0627-020
1998	JAG 340	339	0627-012
1998	JAG 340 DELUXE	339	0627-012
1998	JAG 440	431	0627-012
1998	JAG 440 DELUXE	431	0627-012
1998	PANTERA 580	580	0627-021
1998	PANTERA 800	794	0627-020
1998	PANTHER 340	339	0627-012
1998	PANTHER 440	431	0627-012
1998	PANTHER 550	550	0627-021
1998	POWDER EXTREME	594	0627-020
1998	POWDER SPECIAL 600	599	0627-020
1998	POWDER SPECIAL 600 EFI	599	0627-020
1998	THUNDERCAT	1000	0627-020
1998	THUNDERCAT MOUNTAIN CAT	1000	0627-020
1998	Z 440	431	0627-012
1998	ZL 440	436	0627-021
1998	ZL 500	497	0627-020
1998	ZR 440	437	0627-020
1998	ZR 500	497	0627-020
1998	ZR 600	599	0627-020
1998	ZR 600 EFI	599	0627-020
1998	ZRT 600	594	0627-020
1998	ZRT 800	794	0627-020